

SCE170
Undercounter Cuber

Technical Training

- SCE170
 - Air Cooled or
 - Water Cooled
 - Two piece roto-molded cabinet




- Self Contained Cuber
 - A storage bin is part of the cabinet
- Fits under the counter
 - 24” wide x 39” high x 24” deep
- It can be built in
 - Air flow is in the front and out the front
- Easy to install
- Easy to service

- Includes a power cord
- Plumbing fittings on the back panel
 - A 3/8" male flare water inlet fitting
 - Two 3/4" female pipe thread drains
 - One for the bin
 - One for the purge drain

Bin Drain

Reservoir
Drain



Water Inlet

Keep Drain Tubing Separate!

- Most service can be done with the machine installed
 - The water pump and float valve are inside the hood
 - The control box and air filter are accessible from the front
 - The fan and high pressure reset are accessible from the front
 - The refrigeration system access valves are at the front.

Scotsman®

Installed Built-In






Remove Screws

Scotsman®

Service Access




**Push Down &
Tilt Out**



Bin Drain
Connection

Refrigeration System Access Valve


Hi Pressure Cut Out, was manual reset,
changed to auto-reset in 1998






**Remove Filter
Bracket**

Note: Filter is currently aluminum type - not the foam type as pictured



Twist Filter & Pull it Out

- The cabinet is removable
 - Remove two fasteners and slide the hood forward
 - Remove the grills, disconnect the bin drain and two more fasteners, then the bin may be rotated off of the chassis




Scotsman®

Service Access




**Pull Hood
Forward & Out**




Remove Bin-to-
Chassis Fasteners


NOTICE
USE R404a ONLY
SERVICE PARTS
LOW SIDE HIGH SIDE

Note: Deck Plate
No Longer Used



Note: Air Cooled Unit Cannot Operate As Shown -
Bin or Cover Plate (prior units) Must Be In Place!





Control Box May Be
Moved Up for Service

- The evaporator is high phosphorus, electroless nickel plated copper
- The bin control is a “magnetic” curtain switch, which also acts as a harvest termination control
- A cube size thermostat controls the freeze cycle time.

Scotsman®

Construction: Evaporator





- Shut off valve/strainer just above the float valve
- The water pump forces water thru the tube in the water distributor and over the evaporator




Compression Ring

Water Inlet Fitting






- The water level in the reservoir is maintained by the float valve
 - The typical water level is about 1 and one half inches from the top
- During the Harvest Cycle the purge valve, located behind the pump, is open and the pump forces water out the purge drain
 - Note: The purge drain is a gravity drain and must be properly installed



Remove Float Valve:
Loosen the Shield and
Slide the Valve out of
the Slot





Scotsman® Water Distributor Mounting



Mounting Studs

Cleaning Water System:

The water system is cleaned by pumping a solution of water and citric acid type 100 through the water distributor, down the sprayer and back to the reservoir.

1. Open the door and empty the tank of hot water.
2. Remove the right door gasket.
3. Insert the Water-Cleaner packets, activate the automatic cycle for 2 minutes to flush the tank from the sprayer.
4. Locate and move the ON/OFF/CLEAN switch to CLEAN.
5. Close and raise the cabinet to release the water.
6. After 2 minutes of 1 quart of water (200°F - 175°F) water and 1 quart of citric acid type 100 solution of water, back to the sprayer & repeat this.

7. Lower the purge switch, push it up and hold it up with the assembly to safety empty.
8. Immediately pour the cleaning solution into the reservoir and allow it to circulate through the water system, the 10 minutes.
9. Shut the machine the purge switch up and hold it up, the reservoir is empty empty, or 10. Remove the door plug, water the reservoir & replace the plug.

11. Open the cabinet, turn place the cabinet of the sprayer surface. If it appears clean.

For Maximum Cleaner Solution, Please Consult the User Manual.

It is important to use the correct amount of water to mix. Call your distributor for more information. See the manual for more information.

WARNING





12. After the reservoir is full, close the purge switch up with the reservoir to safety empty. When the reservoir is empty & clean.

13. After the reservoir is full, close the purge switch up with the reservoir to safety empty. When the reservoir is empty & clean.


14. After the reservoir is full, close the purge switch up with the reservoir to safety empty. When the reservoir is empty & clean.
15. The next time you use the water distributor, operation or installation of the water distributor should be done by a trained technician.

Purge Valve
Inlet Port






Purge Valve



Scotsman® Purge Valve Components



- At the beginning of the freeze cycle, the compressor, water pump and fan motor are operating
 - Two lights on the control module will be ON
- When the suction line temperature falls to the cube size thermostat's cut in point (about 8 degrees), power is supplied to an electronic 4 minute timer in the control module

- Indicator Lights
 - Freeze Timer
 - ON when Cube Size Thermostat is CLOSED
 - Curtain Position Lights
 - Both ON when Curtain is FULLY CLOSED
 - Note: Module Position Rotated 90° in 1998

Light is ON when Cube Size Thermostat is CLOSED




- When the electronic timer is On, the Freeze Timer light on the control board will be ON
- At the end of the freeze cycle, the control module switches
 - The fan motor OFF
 - The hot gas valve and purge valves ON
- The machine remains in the Harvest Cycle until the slab of ice falls off, opening the curtain

- After the slab has opened the curtain, if the curtain re-closes the machine will go back into another freeze cycle
- If the bin is full the last slab will keep the curtain open and the machine will switch OFF
 - Note: The curtain may be removed any time during the freeze cycle without causing a problem, however it should not be moved during a harvest cycle

- Check the installation
 - Both drains must be vented
 - Water filter changed
- Check curtain position
- Switch water and power on
- Switch unit on
- Check cube size
 - Complete slab must fall
 - About a 3/16" bridge
 - Maximum of a 1/16" dimple

- Check harvest time
 - Should be about 3 minutes
 - If much longer than 2 minutes
 - Adjust cube size smaller
- Check purge drain
 - Must be free flowing
- Check drains and water supply for any leaks



Curtain Sensor

Curtain Magnet

Scotsman® Cube Size / Bridge Thickness



“Dimple”: NO Deeper than 1/16”

Bridge: About 3/16”

Ice Holding the
Curtain Open Shuts
the Machine OFF.

Curtain



- The SCE170 uses R-404A as a refrigerant
 - Air Cooled - 17 ounces
 - Water Cooled - 9 ounces - A series, 11 ounces - B series, 10 ounces C series
- It uses a hot gas bypass to warm up the evaporator and harvest the ice
- The fan is on all the time in freeze and off during harvest

- Freeze cycle
 - System pressure
 - Discharge declines from about 300 to 210
 - Suction declines from about 60 to 25
- Harvest cycle
 - System pressure
 - Discharge pressure is about 190
 - Suction pressure is about 85 - 90

Scotsman® Freeze - Suction Pressure



Beginning Freeze



Ending Freeze

Scotsman® Harvest - Suction Pressure



- Cycle Times
 - Harvest Cycle
 - 1.5 to 2 minutes
 - Freeze Cycle
 - 12 to 17 minutes
- Batch Weight
 - 1.6 to 1.8 LB per cycle
- Ice Making Capacity
 - 120 LB per 24 hours @ 90/70

Scotsman® SCE170 Service Diagnosis

- Machine is OFF
 - Check power
 - Check master switch
 - Check curtain
 - Must be closed
 - Check control module lights
 - Both lights must be ON
 - Check Hi Pressure Cut Out
 - Cuts out at 450 PSIG (auto-reset after 10/98)

Scotsman® SCE170 Service Diagnosis

- No ice, no water flow
 - Water supply turned off
 - Float valve, strainer or water filter plugged up
 - Purge valve leaks thru
 - Water pump does not pump
- No ice, water flow is very slow
 - Purge valve leaks thru
 - Obstruction in water pump or distributor

Scotsman® SCE170 Service Diagnosis

- No ice, machine is operating
 - Cube size set too small or
 - Purge valve does not open or
 - Purge drain is restricted
 - Ice does not fall thru curtain
 - Maximum harvest time returns unit to freeze cycle

Scotsman® SCE170 Service Diagnosis

- Low ice making capacity
 - Dirty air filter, condenser, or fan blade
 - Purge valve leaks thru
 - Curtain sticks
 - Water system needs de-mineralizing
 - Cube size set MUCH too large
 - Long harvest cycle (> 2 minutes)
 - Cubes slightly too small
 - Occasionally causing maximum (7 minute) harvest cycle

- De-Scale with Scotsman Nickel-Safe Ice Machine Cleaner
 - Defrost using manual Harvest Switch
 - Switch to Clean
 - Mix cleaner: 1 qt water to 1 oz of cleaner
 - Hold Purge Switch until reservoir is empty
 - Pour in Cleaner
 - Circulate for 20 minutes
 - Hold Purge Switch until reservoir is empty

- Changes since introduction:
 - Changed to Auto-Reset High Pressure Cut Out
 - Changed Control Module Position
 - Removed Deck Cover
 - Changed Air Filter Material
 - Compressor Change
 - Water Cooled Condenser Change