

Instructions

For the Change to a Stainless Steel, Wrap-Around Door

1. Remove the original door: Open the door and remove the three screws holding the lower hinge to the cabinet.

Note: Save all screws for re-use.

2. With the door open enough to see both screws at the top door hinge, remove the two screws. The door is now free of the cabinet.

3. Remove both hinges from the door and cabinet.

4. Remove the door handle from the top of the door.

5. Remove filler plate from the top of the door.

6. Attach new door handle to the stainless steel wrapper using the two pan-head screws from the kit.

7. Place cardboard from kit onto channels of original door.

8. Slip the door wrapper over the original door. Be sure it is seated firmly and covers the old door completely.

9. Attach the **new top hinge** to the **cabinet** (use the original screws).

10. Attach the **new bottom hinge** to the **door** (use the original screws).

11. Secure the door to the cabinet, bottom hinge first.

12. Insert machine screws from the kit into top of door where hinge is not attached.

