
## Instructions

## for replacing the electro-mechanical timer and switch with a time delay relay

## Applicable to all models prior to DCE33 "D"

## Parts included with kit:

- Solid state timer relay
- Harness
- · Black/white 7" wire
- (2) Screw #6 x 3/8" pan head
- Screw #8 x 1 1/4" flat head screw
- Timer bracket
- Wiring diagram
- 1. Disconnect electricity to machine.
- 2. Remove control box cover.
- 3. Remove bracket for cube size control and bin level control (4 machine screws & 1 sheet metal screw). Be careful not to kink cube size and bin level tubes.
- 4. Remove existing timer by removing two screws and all wires connected to it.
- 5. Attach timer bracket to control box with two #6 x 3/8" pan head screws. Orient bracket so that the slotted hole is on the bottom.



- 6. Plug in harness to timer as indicated.
  - RED wire (w/2 wires) to "C" on timer.
  - RED wire (wire not bundled) to "1" on timer.
  - PURPLE wire to "6" on timer.
  - BLUE wire to "NO" on timer.
  - · ORANGE wire to "NC" on timer.
  - WHITE wire to "2" on timer.
- 7. Attach new timer to timer bracket using one #8 x 1 1/4" flat head screw. Orient timer so that the adjustment dial is at the bottom.
- 8. Attach PURPLE wire from terminal #6 on timer to terminal #2 on cube size control.
- 9. Attach BLUE wire from "NO" on timer to L03 on board.
- 10. Attach WHITE wire from terminal #2 on Timer to L02 on board.
- 11. Attach ORANGE wire from "NC" on timer to L04 on board.
- 12. Attach RED wire (second wire) from "C" on timer to L05 on board.
- 13. Confirm timer is set for approximately 170 seconds (about 2 3/4 minutes).

14.

**Gravity model**: Remove BLACK wire from bin level control and attach to L01 on board. Attach BLACK/WHITE 7" wire from L01 on board to bin level control.

**Pump model**: BLACK/WHITE wire is not needed - continue to next step.

- 15. Reattach bracket, cube size control and bin level control.
- 16. Connect power and turn bin level to start machine. The machine will start in Harvest cycle. Freeze cycle with start in about 3 minutes. Check cube size and adjust as needed.
- 17. Attach wiring diagram over old diagram on control box cover.
- 18. Reattach control box cover.