



INSTRUCTIONS

1. LOCATE CLIP SO THAT WHEN DOOR IS IN FULLY OPEN POSITION THE EDGE OF THE DOOR IS IN THE CLIP .375".
2. CLIP SHOULD BE LOCATED ON FRONT PANEL SO THAT IT IS AS CLOSE TO THE CENTER OF THE BIN DOOR AS POSSIBLE.
3. AFTER LOCATING POSITION, PLACE CLIP USING DOUBLE SIDED TAPE PROVIDED.