HC400 Parts List


Table of Contents

Cabinet
Air Cooled
Water Cooled
Evaporator
Control Box
Wiring Diagrams

HC400 PARTS ILLUSTRATIONS AND PARTS LISTS

HC400 CABINET ASSEMBLY PARTS LISTING

1	Screw, No. 8 x 1-1/4 Flat Hd. Stainless Steel	03-1419-09	6
2	Lockwasher 1/4 Counter Sunk External Tooth	03-1417-08	10
3	Panel, Top (Enamel)	A23784-006	1
	Panel, Top (Stainless Steel)	A23784-002	1
4	Panel, Front (Enamel)	A23785-005	1
	Panel, Front (Stainless Steel)	A23785-002	1
5	Panel, Left S de (Enamel)	A23782-006	1
	Panel, Left Side (Stainless Steel)	A23782-002	1
6	Panel, Right Side (Enamel)	A23783-006	1
	Panel, Right Side (Stainless Steel)	A23783-002	1
7	Logo Plate, Scotsman	15-0711-01	1
8	Clip	03-0271-00	2
9	Base Drain	02-2296-01	1
10	Screw, No. 8 x 1/2 Stainless Steel	02-1404-10	8
11	Cabinet Frame Assembly	A26178-001	1
	•		




HC400 Cabinet Assembly.

HC400 PARTS ILLUSTRATIONS AND PARTS LISTS

HC400 MAJOR ASSEMBLIES AIR-COOLED PARTS LISTING

1	Cube Size Control	11-0345-02	1
2	Thermostat, Bin	11-0353-03	1
3	Pump Assembly, Water	12-1930-01	1
4	Tube, Tygon (Order by the foot)	13-0674-07	4
5	Clamp, Hose	02-1358-00	4
6	Solenoid Assembly, Water	12-1900-07	1
	Fitting	16-0723-01	1
7	Chute, Cube, includes cover	A27821-001	1
8	Drier	02-2426-01	1
9	Solenoid Valve, Hot Gas	12-2135-01	1
10	Compressor Assembly - 115/60/1	18-4200-01	1
	Compressor Assembly - 208-230/60/1	18-4200-02	1
	Compressor Overload - 115/60/1	18-4200-40	1
	Compressor Overload - 208/230/60/1	18-4200-41	1
11	Screw, No. 5/16 x 18 Hex Machine	03-1405-20	1
12	Washer	03-1407-07	4
13	Sleeve	18-2300-26	4
14	Grommet, Mounting	18-2300-27	4
15	Capacitor, Run - 115/60/1	18-1902-45	1
	Capacitor, Run - 208-230/60/1	18-1902-29	1
16	Capacitor, Start - 115/60/1	18-1901-09	1
	Capacitor, Start - 208-230/60/1	18-1901-15	1
17	Relay - 115/60/1	18-1903-33	1
	Relay - 208-230/60/1	18-1903-29	1
18	Drain Tube Assembly	No Number	1
19	Condenser, Air-Cooled	18-3703-01	1
20	Shroud, Fan	02-2352-01	1
21	Fan Blade - Includes Mtg. Hwd	18-0625-00	1
22	Motor, Fan - Includes Mtg. Hwd 115/60/1	12-1681-01	1
	Motor, Fan - 208-230/60/1	12-1681-01	1
23	Mount, Fan Motor	A25548-001	1
24	Accumulator Suction Line Assembly	A28803-020	1
25	Inlet Valve Fitting	16-0723-01	1

HC400
PARTS ILLUSTRATIONS AND PARTS LISTS




HC400 Major Assemblies Air-Cooled.

HC400 THE PARTS ILLUSTRATIONS AND PARTS LISTS

HC400 MAJOR ASSEMBLIES WATER-COOLED PARTS LISTING

Cube Size Control	11-0345-02	1
Thermostat, Bin	11-0353-03	1
Pump Assembly, Water	12-1930-01	1
Tube, Tygon (Order by the foot)	13-0674-07	4
Clamp, Hose	02-1358-00	4
Solenoid Assembly, Water	12-1900-07	1
Chute, Cube, includes cover	A27821-001	1
Drier	02-2426-01	1
Solenoid Valve, Hot Gas	12-2135-01	1
Compressor Assembly - 115/60/1	18-4200-01	1
Compressor Assembly - 208-230/60/1	18-4200-02	1
Compressor Overload - 115/60/1	18-4200-40	1
Compressor Overload - 208-230/60/1	18-4200-41	1
Screw, No. 5/16 x 18 Hex Machine	03-1405-20	1
Washer	03-1407-07	4
Sleeve	18-2300-26	4
	18-2300-27	4
Capacitor, Run - 115/60/1	18-1902-45	1
Capacitor, Rur - 208-230/60/1	18-1902 -2 9	1
Capacitor, Start - 115/60/1	18-1901-09	1
Capacitor, Start - 208-230/60/1	18-1901-15	1
Relay - 115/60/1	18-1903-33	1
Relay - 208-230/60/1	18-1903-2 9	1
Drain Tube Assembly	No Number	1
Condenser, Water-Cooled	18-3306-02	1
Water Regulator Bracket	A15924-000	1
Water Regulator Valve	11-0198-02	1
Accumulator Suction Line Assembly	A28803-020	1
	Thermostat, Bin Pump Assembly, Water Tube, Tygon (Order by the foot) Clamp, Hose Solenoid Assembly, Water Chute, Cube, includes cover Drier Solenoid Valve, Hot Gas Compressor Assembly - 115/60/1 Compressor Assembly - 208-230/60/1 Compressor Overload - 115/60/1 Compressor Overload - 208-230/60/1 Screw, No. 5/16 x 18 Hex Machine Washer Sleeve Grommet, Mounting Capacitor, Run - 115/60/1 Capacitor, Run - 208-230/60/1 Capacitor, Start - 115/60/1 Capacitor, Start - 208-230/60/1 Relay - 115/60/1 Relay - 208-230/60/1 Drain Tube Assembly Condenser, Water-Cooled Water Regulator Bracket Water Regulator Valve	Thermostat, Bin 11-0353-03 Pump Assembly, Water 12-1930-01 Tube, Tygon (Order by the foot) 13-0674-07 Clamp, Hose 02-1358-00 Solenoid Assembly, Water 12-1900-07 Chute, Cube, includes cover A27821-001 Drier 02-2426-01 Solenoid Valve, Hot Gas 12-2135-01 Compressor Assembly - 115/60/1 18-4200-01 Compressor Assembly - 208-230/60/1 18-4200-02 Compressor Overload - 115/60/1 18-4200-40 Compressor Overload - 208-230/60/1 18-4200-41 Screw, No. 5/16 x 18 Hex Machine 03-1405-20 Washer 03-1407-07 Sleeve 18-2300-26 Grommet, Mounting 18-2300-27 Capacitor, Run - 115/60/1 18-1902-45 Capacitor, Run - 208-230/60/1 18-1902-29 Capacitor, Start - 115/60/1 18-1901-09 Capacitor, Start - 208-230/60/1 18-1901-09 Capacitor, Start - 208-230/60/1 18-1901-09 Capacitor, Start - 208-230/60/1 18-1903-33 Relay - 208-230/60/1 18-1903-33 Relay - 208-230/60/1 18-1903-29 Drain Tube Assembly No Number Condenser, Water-Cooled 18-3306-02 Water Regulator Bracket A15924-000 Water Regulator Valve 11-0198-02

HC400
PARTS ILLUSTRATIONS AND PARTS LISTS




HC400 PARTS ILLUSTRATIONS AND PARTS LISTS


HC400 FREEZER ASSEMBLY PARTS LISTING

	Diede Fee Deisserates	40 0075 05	
1	Blade, Fan - Drivemotor	12-0675-25	1
2	Drivemotor Assembly, Agitator	A24656-001	1
3	Screw, No. 6 x 1 T/F Top	03-1404-28	4
4	Screw, No. 8 x 1/2 Stainless Steel	03-1404-10	4
5	Washer, Centering	A24830-001	4
6	Plug, Hole	02-2065-02	4
7	Spacer, Tube	02-2129-01	1
8	Gasket - Agitator Drivemotor Assembly	13-0176-00	1
9	Cover, Insulation	02-2124-01	1
10	Cover, Freezing Chamber	A24803-001	1
11	Platen Assembly, Cup (Small cubes)	A27218-002	1
	Platen Assembly, Cup (Medium cubes)	A27217-002	1
	Platen Assembly, Cup (Large cubes)	A24129-002	1
12	Fork, Drive (Left-hand thread)	02-2369-02	1
13	Bar Assembly, Spray (w/rubber tips)	A25480-001	1
14	Rubber - Spray Bar Ends	13-0653-00	2
15	O-Ring	13-0617-25	1
16	Bearing, Spray Bar	02-2120-01	1
17	Bottom, Inner	02-2028-01	1
18	Tube, Tygon (8-inch Ig.)(Order by the foot)	13-0674-07	1
19	Clamp, Hose	02-1358-01	2
20	Housing, Inlet	02-2121-01	1
21	Plate, Support - Spray Bar	A23827-001	1
22	Washer, Rubber	A23827-001	1
23	Sump, Freezing Chamber	03-1409-01	1
24	Mount, Front	A24498-001	1
25	Screw, No. 10 x 5/8 cap	03-1404-18	4
26	Plug, Bottom	02-2122-01	1
27	Tube, Female	02-2081-01	4
28	Tube, Female (cut-off)	02-2606-01	1
29	O-Ring	13-0617-02	5
30	Tube, Male	02-2080-01	3
31	Pipe, Stand	02-2125-01	1
32	Tube, Pick-Up-Pump	02-2082-01	1
	and the second of the second o		-

HC400
PARTS ILLUSTRATIONS AND PARTS LISTS




HC400
PARTS ILLUSTRATIONS AND PARTS LISTS



HC400 CONTROL BOX ASSEMBLY PARTS LISTING

1	Contactor - 115/60/1	12-2041-01	1
	Contactor - 208-230/60/1	12-2037-01	1
2	Screw, No. 8-32 x 3/8	03-1403-17	3
3	Switch	12-0426-01	2
4	Screw, No. 6-32 x 1/4 Phil Recess Pan Hd	03-1403-02	2
5	Timer and Switch Assembly	12-1980-01	1
6	Stand-Off, 7/8-long	02-2242-01	2
7	Screw, No. 6-32 x 1/4 Phil Recess Pan Hd	03-1403-02	2
8	Relay - 115/60/1	12-1879-02	1
	Relay - 208-230/60/1	12-1879-02	1
9	Screw, No. 6-32 x 1/4 Phil Recess Pan Hd	03-1403-02	5
10	Circuit Board	12-1912-01	1
11	Stand-Off, 5/8 inch	02-2242-02	5
12	Control, Hi Pressure (Water-Cooled)	11-0388-02	1
13	Screw, No. 6-32 x 1/4 Phil Recess Pan Hd	03-1403-04	2
14	Bushing, Snap	12-1213-13	1
15	Bushing, Snap	12-1213-10	3


HC400 WIRING DIAGRAMS



Air-Cooled 115/60/1

AUGUST 1983 Page 27


HC400 WIRING DIAGRAMS



Water-Cooled 115/60/1

AUGUST 1983 Page 28


HC400 WIRING DIAGRAMS



Air-Cooled 115/208-230/60/1

AUGUST 1983
Page 29

HC400 WIRING DIAGRAMS



Water-Cooled 115/208-230/60/1

AUGUST 1983

Page 30