

# CME810

Symptom: Ice jams up

Likely Cause: End Deflector Out of Position



The End Deflector must be in place as shown here. The End Deflector routes the ice towards the cube chute outlet AND holds the cube deflector so it does not move.

If the thumb screw is missing the End Deflector can be out of place or it can be put on wrong.



**Correct**, End Deflector positioned to route ice to chute and to hold cube deflector in place.



**Incorrect**

Edge of End Deflector caught on sump wall