

Two Drip Stops are located on the inside left and inside right of the freezing compartment as seen above.

If the drip stops are too wide they can hang up the curtain.

The left stop MUST NOT extend more than 1/8 inch into the freezing compartment. Some units were manufactured with the wrong size left drip stop.

If it is too big, trim it:

Trim width to 1/8 inch Trim top back as shown

