

## SERVICE BULLETIN


### Subject: CU0515 Cube Size and Bin Thermostat Locations

The Cube Size Thermostat on this model is the control with the plastic knob. It is located on the right side of the front of the control box. The bin thermostat is located on the left.

Two batches of units were manufactured with the thermostat positions reversed:

- From s.n. 0710 1320 011109 to 0710 1320 011128
- From s.n. 0711 1320 011493 to 0711 1320 011616

All documentation shows them the correct way.



*Cube Size and Bin Thermostats, shown in their correct positions.*