

# SERVICE BULLETIN

---

## **Subject: Cuber TXV Changes**

Several models are changing to a Danfoss thermostatic expansion valve.

### **C0522, C0530 and C0630**

The expansion valve used in these three models has been changed:

Prior part number 16-1117-21 (cross referenced to 16-1117-01).

New part number **16-1182-01**

Application: 16-1182-01 and 16-1117-01 are interchangeable on these models.

This change began with serial number 11011320014550.

### **C0322 and C0330**

The expansion valve in these models has also changed:

Prior part number 16-1117-23 (cross referenced to 16-1117-03)

New part number **16-1183-01**

Application: 16-1183-01 and 16-1117-03 are interchangeable on these models.

### **CU1526**

The expansion valve in this model has also changed:

Prior part number 16-1117-24 (cross referenced to 16-1117-04)

New part number **16-1183-01**

Application: 16-1183-01 and 16-1117-04 are interchangeable on this model.

### **CU2026**

The expansion valve in this model has also changed:

Prior part number 16-1117-25 (cross referenced to 16-1117-05)

New part number **16-1183-01**

Application: 16-1183-01 and 16-1117-05 are interchangeable on this model.

### **CU3030**

The expansion valve in this model has also changed:

Prior part number 16-1117-23 (cross referenced to 16-1117-03)

New part number **16-1183-01**

Application: 16-1183-01 and 16-1117-03 are interchangeable on this model.

### **EH130**

The expansion valve in this model has also changed:

Prior part number 16-1117-02

New part number **16-1184-01**

Application: 16-1184-01 and 16-1117-02 are interchangeable on this model.