



**Place Container Under Chute. Machine dispenses until container is removed or dispense time is up, whichever is first.**

### Using the MDT2

#### Defaults:

- Selection: Ice
- Dispensing Time: 5 Seconds

Option: Setting the dispensing time. To modify the original setting time of 5 seconds.

1. Push and hold the 4th switch (CONTINUOUS) for 10 seconds until the lights start to blink.

2. Select desired dispense time

- Push & release the 1st switch (ICE) for a **5** second dispense.
- Push & release the 2nd switch (ICE AND WATER) for a **10** second dispense.
- Push & release the 3rd switch (WATER) for a **15** second dispense.

The unit resumes a default dispense setting (Ice, Ice and Water or Water) after each dispense.

Option: Selection. To modify the default selection mode from factory set to ICE push and hold the desired switch (ICE, ICE AND WATER or WATER ) for 5 seconds.