

### **Subject: Prodigy, AutoSentry and RO Water**

RO (Reverse Osmosis) purified water is available in several grades of purity. The typical grade of RO water used as the water supply for a Prodigy cuber or an AutoSentry controlled Flaker\* works fine. However, ultra-pure water that does not conduct electricity will interfere with the ice machine's operation. If the water is so pure (as water becomes more pure its ability to conduct electricity is reduced) that electricity cannot be conducted, the conductivity probe in the reservoir cannot sense the presence of water and will not allow the machine to start.

- The conductivity level for the water supply to Prodigy models must be no less than 10 micro/Siemens / cm.
- The conductivity level for the water supply to AutoSentry models must be no less than 35 micro/Siemens / cm.
- cm.

If you require any additional information, contact Scotsman Technical Service.