

Instructions

for the installation of condenser coil filters on ERC111 or ERC311 remote condensers.

Kit Contents:

Two upper filter retention brackets.
Four lower filter retention brackets.
Two filters

1. Shut ice machine off.
2. If condenser is powered separately, disconnect power to it.
3. Work on one side at a time. Remove top two screws holding legs to condenser.
4. Remove screws holding top cross brace.
5. Place filter media over coil. Bottom end slips between coil and bottom bracket of condenser.
6. Attach upper filter retaining bracket to condenser using screws removed in stop 4.
7. Attach filter retention brackets to condenser using screws removed in stop 3.
8. Repeat above for opposite side.
9. Return power to condenser, switch ice machine back on.