

Instructions



For installing bin top adapter KBT34-2X

Adapter function: Placing two CME686 or CME810 or EH222 ice machine heads on a BH900 or B948S ice storage bin.

1. Uncrate bin and ice machines.
2. Do all necessary rough-in work in preparation for ice machine and bin installation.
3. Attach legs to bin.
4. Place KBT34-2X adapter on bin. The stainless steel strip in the middle of one side goes DOWN facing the ice.

Note: Be sure the ice drop zone holes are closer to the back of the bin than the front.

5. Place both ice machine heads on the adapter.



6. Secure ice machine heads to the adapter and the bin using one mounting bracket each. Use the supplied brackets and hardware.
7. Complete the installation.