

Instructions

Bin Top KBT37-2X

Adapter function: Placing two CME686 or CME810 or EH222 ice machine heads on a BH900 or B948S ice storage bin.

1. Uncrate bin and ice machines.
2. Do all necessary rough-in work in preparation for ice machine and bin installation.
3. Attach legs to bin.
4. Place KBT37-2X adapter on bin. Secure to the bin using two supplied bolts.
5. Place both ice machine heads on the adapter.
6. Secure ice machine heads to the adapter and the bin using the brackets and hardware supplied with the ice machines.
7. Complete the installation.