Instructions

for the installation of bin top adapter, KBT34

The KBT34 adapter is designed to allow the placement of a CME686 or CME810 or an EH222 onto a Scotsman B948 ice storage bin. The adapter is made up of **three parts**, a 30" wide **plastic section** and two **stainless steel filler plates**. Hand tools will be required to install this adapter.

The KBT34 contains:

- One 30" x 24" plastic ice machine support
- Two stainless steel filler plates with attached insulation.
- Two mounting brackets
- Six 5/16 18 cap screws
- Two 8-32 machine screws
- Four #10 flat washers
- Six 5/16 flat washers
- One tube of RTV sealant
- 1. Place the large plastic ice machine support in the center of the bin's top area.
- 2. Place one stainless steel filler plate on each side of the plastic ice machine support. The open end goes over the canopy.
- 3. Secure the stainless steel filler plates to the bin with one bolt in each.
- 4. Locate the ice machine attachment brackets. Use them to secure the plastic ice machine support to the bin using the bolts and washers from the kit.
- 5. Seal the junction point of the stainless steel filler plates and the plastic ice machine support with a bead of food grade sealant from the tube in the kit.
- 6. Complete the ice machine installation. Use brackets from step 4 to attach ice machine to bin.



Right Bracket, Viewed from the Back